



Обозначение	Размеры, мм							
	D	L	B	H	H1	S	d	d1
СМО 10-11	10	26,5	10	11	9	1	4	6
СМО 12-13	12	28,5	10	13	11	1	4	6
СМО 14-15	14	30,5	10	15	11	1	4	6
СМО 16-17	16	32,5	10	17	13	1	4	6
СМО 19-20	19	35,5	12	20	16	1	4	6
СМО 21-22	21	37,5	12	22	16	1	4	6
СМО 24-25	24	40,5	12	25	20	1	4	6
СМО 25-26	25	41,5	12	26	20	1	4	6
СМО 31-32	31	51	16	32	24	1,2	6	8
СМО 38-40	38	59	16	40	33	1,2	6	8
СМО 48-50	48	69	16	50	45	1,2	6	8